



FUNCTION

The Computer Interface Module, model UPIM-01, is used to exchange digital commands between a PC (personal computer) and UPB (Universal Powerline Bus) devices in the home. The module communicates these commands over the AC power wiring. The UPIM-01 provides a USB interface with a USB cable for configuration of UPB lighting only. The UPIM-01 is not recommended for home automation controllers (use the SPIM-01 instead).

UPB devices can be freely located anywhere in the home. No additional wiring is required and no radio frequency signals are used.

IMPORTANT SAFETY INSTRUCTIONS

When using electrical products, basic safety precautions should always be followed, including the following:

1. READ AND FOLLOW ALL SAFETY INSTRUCTIONS.
2. Keep away from water. If product comes into contact with water or other liquid, unplug immediately.
3. Never use products that have been dropped or damaged.
4. Do not use this product outdoors.
5. Do not use this product for other than its intended use.
6. To avoid risk of fire, burns, personal injury and electric shock, install this product out of reach of small children.
7. Do not cover the product with cloth, paper or any material when in use.
8. This product uses polarized plugs and sockets (one blade is wider than the other) as a feature to reduce the risk of electric shock. These plugs and sockets fit only one way. If they do not fit, contact a qualified technician. Do not use with an extension cord unless plugs can be fully inserted. Do not alter or replace plugs.
9. SAVE THESE INSTRUCTIONS.

INSTALLATION

The Computer Interface Module is designed for indoor use.

1. The first time the UPIM-01 is used, turn on the computer without the UPIM-01 connected.
2. Plug the Computer Interface Module into a 120-volt outlet near the computer or server.
3. Connect the supplied interface cable to the socket on the **bottom** of the module. Connect the other end of this cable to an available USB port on the computer.
4. Run the UPStart UPB configuration software or other UPB interface software and establish communications with the UPIM-01 and the UPB network.
5. Once communication is established between the host PC and the UPIM-01, the computer can be turned off or on with the UPIM-01 connected.

OPERATION

The Computer Interface Module exchanges UPB messages between the powerline and the connected computer or controller. The indicator on the module will glow AMBER when powered and flash RED during messaging.

The interface has two operating modes: MESSAGE mode and PULSE mode. The last-used operational mode is retained during power interruption. UPStart software automatically sets the interface to PULSE mode operation, but most controllers require MESSAGE mode. To restore MESSAGE mode operation...

1. Place the UPIM-01 in SETUP mode by pressing the Program Switch (located just above the indicator) five times rapidly using a non-metallic toothpick. The indicator will continuously blink RED.
2. Reset to MESSAGE mode by pressing the Program Switch ten times. The indicator will continuously blink GREEN.
3. Press the Program Switch twice to exit SETUP mode.



CAUTION: Do not insert metal objects into the module while it is connected to power.